



Procedure for starting units after "Airflow Fail" (Cylon Controller)

1. Mute alarm
2. Turn on Fan MCB
3. Enter password UUDDUD
4. Go to level 2
5. Go to level 1.6 Maintenance.
6. Go to level 11.12 Reset Airflow Fail
7. Press Tic to change to on.
8. Fans should start.
9. When the unit re-starts ensure that the relay marked "AFR" is energised. This shows the correct operation of the "Airflow Switch" (if the relay is not energised the airflow switch dial will require adjusting to a lower value).
10. Finally, change the "AIRFLOW FAIL RESET" value from "ON" back to "OFF".

Please note: Check the correct operation of the "AIRFLOW SWITCH" by switching off fan for approximately ten seconds. Ensure that the "AFR" relay de-energises. This should then re-energise when the fan MCB is switched back on.